

*Translation of the original instructions  
Assembly Instructions*

# Positive Displacement Pumps FK/FL Series

Pump Type:

Pump No.:





## Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>5</b>	6.4	Pump Fixation .....	11
1.1	Foreword.....	5	6.5	Installation of Pipes .....	12
1.2	Manufacturer .....	5	6.6	Electrical Connection .....	12
1.3	Scope of Supply.....	5	6.7	Connection of Sealing or Quenching Liquid (Optional) .....	12
1.4	Pump Without Motor (Optional) .....	5	6.8	Cleaning.....	12
1.5	Scope of Documentation.....	5			
1.6	Basic Safety Instructions.....	5	<b>7</b>	<b>Operation .....</b>	<b>13</b>
1.7	Display Conventions.....	5	7.1	Safety Instructions .....	13
			7.2	Commencement of Operation .....	13
<b>2</b>	<b>Safety.....</b>	<b>6</b>	7.3	Monitoring of Operation .....	13
2.1	Intended Use .....	6	7.4	Stopping of Operation .....	13
2.2	Predictable Misuse .....	6	7.5	Pump Decommissioning .....	13
2.3	Pump-Specific Safety Instructions .....	6			
2.4	Warning and Instruction Labels.....	6	<b>8</b>	<b>Cleaning in Place.....</b>	<b>14</b>
2.5	Noise Emissions .....	7	8.1	CIP Process.....	14
2.6	Disposal .....	7	8.2	SIP Process .....	14
<b>3</b>	<b>Design and Function .....</b>	<b>7</b>	<b>9</b>	<b>Faults .....</b>	<b>14</b>
3.1	Principles of Design.....	7	9.1	Safety Instructions .....	14
3.2	Models .....	8			
3.3	Basic Versions .....	8	<b>10</b>	<b>Maintenance .....</b>	<b>14</b>
3.4	Pump Sizes .....	9	10.1	Safety Instructions .....	14
3.5	Accessories .....	9	10.2	Replacement Parts .....	15
3.6	Type Designation.....	9	10.3	Inspection of Sealing and Quenching Liquid (Optional) .....	15
			10.4	Oil Level Check.....	15
<b>4</b>	<b>Transportation.....</b>	<b>9</b>	10.5	Oil Change .....	15
4.1	Safety Instructions .....	9	10.6	Oil and Grease Change for FL 130.....	16
4.2	Moving With Industrial Truck .....	10	10.7	Lubrication of Motor Bearings.....	16
4.3	Moving With Crane .....	10	10.8	Shaft Seal Replacement .....	16
			10.9	Pump Head Removal .....	16
<b>5</b>	<b>Storage .....</b>	<b>10</b>	10.10	Pump Head Attachment.....	17
5.1	Pump Storage Conditions.....	10	10.11	Shaft Bearing Replacement .....	22
5.2	Long-Term Pump Storage .....	11	10.12	Coupling Replacement.....	22
5.3	Recommissioning .....	11	10.13	Gear Motor Replacement .....	22
			10.14	Checking of the Clearances .....	23
<b>6</b>	<b>Installation .....</b>	<b>11</b>			
6.1	Safety Instructions .....	11			
6.2	Installation Location .....	11			
6.3	Reduction of Noise and Vibration.....	11			

<b>11</b>	<b>Appendix 1 .....</b>	<b>26</b>
11.1	Specifications .....	26
11.2	Maintenance Intervals.....	27
11.3	Lubricant (Grease) Table .....	27
11.4	Troubleshooting Table .....	27
11.5	Number Key .....	30
11.6	Declaration of Conformity .....	31
<b>12</b>	<b>Appendix 2 – Assembly Instructions (Optional) .....</b>	<b>33</b>
12.1	Safety Instructions .....	33
12.2	Scope .....	33
12.3	Rating Plate .....	33
12.4	Moving Without Motor .....	33
12.5	Installation Location .....	34
12.6	Pump Installation.....	35

## 1 Introduction

### 1.1 Foreword

This operator's manual describes all sizes, models, and versions of the FK-and FL-Positive Displacement Pumps.

Information on the model, size, version, and accessories applicable to your pump can be found on the rating plate on your pump and in the "Order-Related Documents" in the attached documents.

### 1.2 Manufacturer

FRISTAM Pumpen KG (GmbH & Co.)

Kurt-A.-Körber-Chaussee 55

21033 Hamburg

GERMANY

Tel.: +49-40-72556-0

Fax: +49-40-72556-166

E-mail: info@fristam.de

### 1.3 Scope of Supply

The package includes the following items:

- Pump with gear motor (= pump unit)  
optional: without motor
- *Fristam* accessories (if applicable)
- Covers for pipe fittings
- Optional: assembly kit
- Documentation
- ▶ Check the shipment for completeness and damage. Immediately notify *Fristam* of any missing items or damage.

### 1.4 Pump Without Motor (Optional)

The pump can optionally be supplied without a motor. In this case, continue reading up to and including Chapter 3, "Design and Function", and then skip to Chapter 12, "Appendix 2 – Assembly Instructions (Optional)," page 33.

### 1.5 Scope of Documentation

The documentation includes the following items:

- **This operator's manual**
  - Appendix 1 with maintenance, lubrication, and tightening torque tables
  - Appendix 2 with assembly instructions
- **Attached documents**
  - Order-Related Documents

- Supplier Documentation (motor, coupling, etc.)
- Documentation on Fristam accessories (if applicable)
- Certificates (materials certificates, etc.), if applicable
- Declaration of Conformity or Declaration of Incorporation

### 1.6 Basic Safety Instructions

Please read this operator's manual completely before using the pump and keep it available at the pump installation location.

Heed the applicable national regulations of the owner's country and the company's work and safety regulations.

Danger of contamination: Heed legal and operational safety regulations when pumping dangerous media.

All work described in this operator's manual may only be performed by qualified experts with caution.

### 1.7 Display Conventions

List items are preceded by dashes:

- Part 1
- Part 2

Handling instructions that must be performed in a specified order are numbered:

1. Turn device on.
2. Turn device off.

Handling instructions that do not need to be performed in a specified order are preceded by triangular bullets:

- ▶ Action
- ▶ Action

#### 1.7.1 Safety Instructions

##### **⚠ DANGER**

A safety instruction with the signal word "Danger" indicates personal hazards causing death or serious injury.

##### **⚠ WARNING**

A safety instruction with the signal word "Warning" indicates personal hazards that may lead to death or serious injury.

##### **⚠ CAUTION**

A safety instruction with the signal word "Caution" indicates personal hazards that may lead to mild to moderate injuries.

##### **NOTICE**

A safety instruction with the signal word "Note" warns of the possibility of material damage.

## 2 Safety

### 2.1 Intended Use

The standard versions of the FK-and FL-Positive Displacement Pumps are designed for use in the food industry, the pharmaceutical and biotechnology industry, and CIP process technology.

The FK-and FL-Positive Displacement Pumps are designed for pumping media at version- and size-specific maximum temperatures and pressures. See *Chapter 11.1, "Specifications," page 26.*

The pump flow direction can be selected freely. The FK pump can generate a vacuum in the suction line.

Each pump is designed according to customer requirements. The seal materials have been selected for the respective medium.

The pump may only be used under the operating conditions specified in the order. See *Order-Related Documents.* For other operating conditions, please contact *Fristam.*

### 2.2 Predictable Misuse

The standard versions of the FK-and FL-Positive Displacement Pumps may not be used in explosive atmospheres. Special explosion-proof versions are available for this.

Pumping of foreign objects with the medium can block and destroy the pump.

Pumping of media other than that specified can destroy the pump. The pumps and the seal materials (elastomers) have been selected for specific pumping media.

Standard pump units from *Fristam* are described in this operator's manual. If nonstandard items or extras are installed, the operator assumes the responsibility for operation.

### 2.3 Pump-Specific Safety Instructions

#### Impermissible Pressure Range

Personal injury and material damage from leakage or bursting of pump.

- ▶ Maintain the pump pressure within the specified pressure range. See *Chapter 11.1.2, "Maximum Discharge Pressures," page 26.*

#### Impermissible Temperature Range

Personal injury and material damage from leakage or bursting of pump.

- ▶ Maintain the pump temperature within the specified temperature range. See *Chapter 11.1.3, "Maximum Medium Temperatures," page 26.*

#### Cold Firefighting Water on Hot Pump

Material damage.

- ▶ When extinguishing a fire do not point the water jet at the pump.
- ▶ Let pumps cool down as slowly as possible.

#### Hot Pump Surface

Contact burns from touching the pump.

- ▶ Check the temperature before touching the pump.
- ▶ Only touch the pump if you are wearing suitable gloves.

#### Noise Emissions From Running Pump

Permanent hearing damage. The A-weighted sound pressure level of the pump can be greater than 80 dBA.

- ▶ Always wear ear protectors in the vicinity of the running pump.
- ▶ The local noise exposure regulations must be complied with.

### 2.4 Warning and Instruction Labels

- ▶ Do not alter or remove the labels on the pump.
- ▶ Immediately replace damaged or lost labels with ones that are true to the originals.

#### 2.4.1 Hot Surface



Fig. 1 Safety label: "Hot Surface"

This label indicates that parts can become hot during operation or, if applicable, that hot media is being pumped. Check the temperature before touching the pump. Only touch the pump if you are wearing suitable gloves.

#### 2.4.2 No Dry Running




Fig. 2 Safety label: "No Dry Running"

This label indicates that the pump cannot be run dry. There must always be medium in the suction line and the pump when the pump is started. Otherwise, the pump will be damaged.

## 2.4.3 Rating Plate




Fig. 3 Pump unit rating plate

1	Manufacturer
2	Type: pump series, pump size, model, version
3	SN: serial number of the pump
4	H: discharge head [m]
5	P: motor output [kW]
6	Year of manufacture
7	m <sub>tot</sub> : mass (total) [kg]
8	n <sub>R</sub> : rated gear speed [1/min]
9	Q: flow rate [m <sup>3</sup> /h]
10	CE mark

## 2.5 Noise Emissions

### CAUTION

#### Noise Generated by Running Pump

Hearing damage.

- ▶ Wear ear protectors when using pumps with specified sound pressure levels of greater than 80 dBA.

## 2.6 Disposal

### 2.6.1 Disposal of Transportation Package

- ▶ Recycle the transportation package.

### 2.6.2 Disposal of Grease

- ▶ Dispose of grease and objects saturated with grease in an environmentally friendly manner in accordance with applicable regulations.

### 2.6.3 Disposal of Lubricating Oil

- ▶ Dispose of oil and objects saturated with oil in an environmentally friendly manner in accordance with applicable regulations.

## 2.6.4 Disposal of Pump

1. Dispose of dangerous or toxic residue in an environmentally friendly manner in accordance with applicable regulations.
2. Carefully clean the pump.
3. Dismantle the pump into its constituent parts.
4. Dispose of the pump parts in an environmentally friendly manner in accordance with applicable regulations.

## 2.6.5 Disposal of Electrical and Electronic Scrap

- ▶ Dispose of electrical and electronic scrap in accordance with applicable directives.

## 3 Design and Function

### 3.1 Principles of Design




Fig. 4 Principles of design illustrated using the FL positive displacement pump

A	Pump with synchromesh gears
B	Coupling
C	Gear motor

### 3.1.1 Pump With Synchromesh Gears (A)




Fig. 5 Principles of design illustrated using the FL positive displacement pump

11	Gearbox
12	Drive shaft
13	Synchronizing shaft
14	Pipe fittings
15	Pump cover
16	Pump casing

### 3.1.2 Coupling (B)

The coupling connects the gear motor shaft to the drive shaft (12) of the pump. The driving torque is transmitted from the gear motor to the pump via the coupling.

Model FKF: The coupling is omitted.

### 3.1.3 Gear Motor (C)

The gear motor is an electric motor with either fixed or variable speed. It is screwed to the base frame or the foundation.

## 3.2 Models

The model and version are indicated on the rating plate. See Chapter 2.4.3, "Rating Plate," page 7.

The FK and the FL/FL2 differ in terms of the pumping element shape. The FK, FL, and FL2 are described in the following sections.

### 3.2.1 Model FK

The FK positive displacement pumps are circumferential piston pumps. They are equipped with pumping elements in the following forms:




Fig. 6 1-wing rotor



Fig. 7 2-wing rotor

### FK Versions

The respective version is indicated on the rating plate; see Chapter 3.6, "Type Designation," page 9.

- High-pressure version with cover bushing
- Compact FKF

This version has no coupling. The pump is flange-mounted on the gear motor.

### 3.2.2 Model FL

FL positive displacement pumps are rotary piston pumps. They are equipped with pumping elements in the following forms:




Fig. 8 1-wing rotor




Fig. 9 2-wing rotor




Fig. 10 3-lobe rotor

The principles of design are the same for the FL and the FL2. They differ in their shaft seals.

### FL and FL2 Versions

- Short or long rotors

This version enables further adaptation to the output requirements of the pump.

## 3.3 Basic Versions

For all models, the following versions are available:

- Single or double shaft seal

Two seal types are available for use: single and double shaft seals.

With the double shaft seal, there are two additional connections for the sealing liquid on the pump casing. These connections are not shown in the figures in this operator's manual.

- High-temperature rotors

High-temperature rotors are special rotors that can be used in FK-and FL-Positive Displacement Pumps to pump media at elevated temperatures. The clearance is larger in high-temperature rotors. See Table 8, "Clearances," page 24.

- Horizontal or vertical pump connection
- Heating jacket

The pump cover and the casing can each be equipped with a heating jacket.

- Relief valve

The relief valve is a safety valve located on the pump cover. If a relief valve is supplied, the corresponding operating instructions can be found in the attached documents.

- Rectangular inlet

The rectangular inlet is an enlarged opening of the suction port.

### 3.4 Pump Sizes

Model FL	Model FL2	Model FK
FL 55	FL2 50	FK 25
FL 75	FL2 55	FK 25/30
FL 100	FL2 58	FK 40
FL 130	FL2 75	FK 40/45
	FL2 100	FK 48
	FL2 130	

Table 1 Pump sizes

### 3.5 Accessories

The FK-and FL-Positive Displacement Pumps can be equipped with the following accessories, among others:

- Enclosure

Stainless steel enclosure for the gear motor. The enclosure is fastened to the base frame.

- Spherical cap bearings

Depending on the design, the spherical cap bearings are attached to the base frame or the gear motor for setup of the pump.

Other accessories are available. If you have any questions, please contact *Fristam*.

### 3.6 Type Designation




Fig. 11 Type designation example

17	Pump type
18	Supplementary character 1
19	Pump size
20	Supplementary character 2

#### (17) Pump Type

- FK Circumferential piston pump, self-priming
- FL Rotary piston pump
- FL2 Rotary piston pump

#### (18) Supplementary Character 1

- F For FK 25-40/45: with flange, without coupling
- FN For FK 25-40/45: drive with coupling
- N For FK 48: drive with coupling
- H For FK: high-pressure versions with cover bushings
- S Vertical connections
- V For FK: double seal
- Ü Relief valve

#### (19) Pump Size

- XX Pump size number
- S For FL and FL2: short model
- L For FL and FL2: long model

#### (20) Supplementary Character 2

- H Pump casing with heating jacket
- h Pump cover with heating jacket
- R Rectangular inlet

Note: If the (optional) pump without motor is supplied, please first read Chapter 12, "Appendix 2 – Assembly Instructions (Optional)" on page 33.

## 4 Transportation

Transportation may only be performed by trained personnel. The pump can be moved using an industrial truck or a crane.

### 4.1 Safety Instructions

#### Falling or Unsecured Parts

Severe crush injuries.

- ▶ Always wear gloves when performing transportation-related work.

#### Incorrect Positioning of Pump for Transportation

Leakage of caustic, toxic, or contaminating liquids. Personal injury and material damage from contamination.

- ▶ Always move the pump in the installation condition.

#### Open, Unsealed Pipe Fittings

Material damage from contamination, impact, or moisture in the pump.

- ▶ Remove the pipe fitting covers just prior to connection to the pipes.

## 4.2 Moving With Industrial Truck

### **⚠ WARNING**

#### Unsecured Parts

Serious injuries, pinching of extremities, material damage.

- ▶ Before moving the pump secure it to prevent it from tipping over. Secure the pump to the pallet with tie-down straps, or screw the pump to the pallet.

Information on pump weight can be found on the pump's rating plate as well as in the *Order-Related Documents* in the attached documents.

#### Preparation

- ▶ Ensure that the pump is adequately secured to the pallet, for example, with straps; see Fig. 12, "Moving with industrial truck," page 10.

#### Procedure

1. Pick up the pallet with the forks on the industrial truck.
2. Carefully move the pallet to the designated location and set down.




Fig. 12 Moving with industrial truck

## 4.3 Moving With Crane

### **⚠ WARNING**

#### Falling Parts

Death from crushing, severe pinching of extremities, material damage.

- ▶ Only use suitable means of conveyance and hoists. Information on the pump weight can be found on the pump's rating plate as well as in the *Order-Related Documents* in the attached documents.
- ▶ Do not lift the pump unit at the eyebolt on the motor or the pump to move because these eyebolts are not designed for the total weight of the pump unit.
- ▶ Do not leave the pump in a raised position for longer than necessary.
- ▶ Ensure that the area below the pump is clear of people.

### **⚠ WARNING**

#### Swinging Parts

Crushing and serious injuries.

- ▶ Start and stop the crane with pump smoothly.
- ▶ Ensure that the danger zone of the pump is clear of people.

#### Auxiliary Equipment

Hoists: round slings tested in accordance with DIN EN 1492-1 and 1492-2

#### Preparation

- ▶ Remove load-securing devices.

#### Procedure

1. **Warning:** Round sling damage and tearing. Death from crushing, severe pinching, material damage.
  - ▶ Do not lay the round sling over any sharp edges or corners.

Wrap the round sling around the gear motor; see Fig. 13, "Moving with round sling illustrated using the FL 100," page 10.
2. Wrap the other end of the round sling around the pump casing; see Fig. 13, "Moving with round sling illustrated using the FL 100," page 10.
3. For double shaft seal:
  - Note:** Round sling compresses sealing water tubes. Material damage to double shaft seal.
  - ▶ Do not lay the round sling on the sealing water tubes.
4. Guide both loops to the crane hook, rotate, and hook over the hook to ensure that the belt will not slip on the hook.
5. Position the center of gravity to ensure that the pump is lifted horizontally.
6. Lift the pump.




Fig. 13 Moving with round sling illustrated using the FL 100

## 5 Storage

### 5.1 Pump Storage Conditions

Store the pump as follows:

- Dry, in low humidity

- Protected against frost and heat, optimally at a temperature of 20°C to 25°C
- Ventilated
- Dust-free
- ▶ All movable pump parts must be rotated every three months.

## 5.2 Long-Term Pump Storage

For a storage time of longer than six months, heed the following:

- ▶ The shaft seals must be completely removed and stored separately before long-term storage of the pump.

See Chapter 10.9, "Pump Head Removal," page 16 and Chapter 5.2.1, "Storage of Elastomers," page 11.

### 5.2.1 Storage of Elastomers

Store the elastomers as follows:

- Storage temperature between +5°C and +20°C
- Relative air humidity below 70%
- No direct sunlight
- Deformation-free storage

## 5.3 Recommissioning

- ▶ After long-term storage and before commissioning, check seals, bearings, and oil level.

# 6 Installation

## 6.1 Safety Instructions

### Falling or Unsecured Parts

Severe crush injuries.

- ▶ Always wear gloves when performing installation-related work.

### Incomplete, Unstable Installation

Severe crush injuries, material damage.

- ▶ Tighten screws to the specified tightening torque; see Chapter 11.1.1, "Tightening Torques," page 26.
- ▶ Use a torque wrench or an impact driver with adjustable torque.

### During Adjustment of Spherical Cap Feet: Swinging

Material damage to system and pump.

- ▶ Use spherical cap base plates.

## 6.2 Installation Location

For standard pumps, the installation location must meet the following requirements:

- Nonexplosive atmosphere
- Dust-free environment
- Ambient temperature: –20°C to +40°C
- Moisture and salt contents in ambient air:  
The values are given in the "Motor Operator's Manual;" please see the attached documents.
- Foundation sized adequately for the pump weight
- Horizontal and level installation surface, adequate installation surface strength for pump mass
- Installation clearances from the "Motor Supplier Documentation"
- Adequate clearance for maintenance work
- Adequate air supply for motor cooling

## 6.3 Reduction of Noise and Vibration

### 6.3.1 Primary Measures

- Operate the pump in the optimum working range.
  - ▶ Operate the pump without cavitation (see Chapter 6.5, "Installation of Pipes," page 12).
- Decouple the suction and discharge lines from vibrations.
  - ▶ Support lines.
  - ▶ Align lines.
  - ▶ Install vibration dampers.

### 6.3.2 Secondary Measures

- ▶ Take structural measures such as the following:
  - Acoustic paneling
  - Enclosure in housing

## 6.4 Pump Fixation

### 6.4.1 Pump With Base Frame

- ▶ Screw the pump on the base frame to the foundation.

### 6.4.2 Pump With Base Frame on Spherical Cap Bearings (Optional)

- ▶ Set up the pump on the spherical cap bearings and align.

### 6.4.3 Carriage (Optional)

1. Set up the pump at the installation location. Lock the locks on the rollers (if present) or secure the carriage with chocks.
2. Ground the carriage to dissipate electrostatic charge.

- 3. Position hose line to ensure that it cannot be damaged.

## 6.5 Installation of Pipes

Lay and connect pipes as follows:

- ▶ Keep the pipe resistance as low as possible: Avoid unnecessary installation of valves, elbows, and abrupt pipe transitions.




Fig. 14 Pipe transitions

- ▶ Design pipe cross section so that no unnecessary pressure losses or cavitation occurs in the suction and inlet areas.
- ▶ Install a shut-off valve in the discharge line.
- ▶ Design the suction lines to be as short as possible.
- ▶ Always lay the suction lines so that they are continuously rising toward the pump unit. Rule out the possibility of air pockets and dips in the pipes.




Fig. 15 Air pocket in pipe




Fig. 16 Dip in pipe

- ▶ Lay and connect the pipes to ensure that no stresses are applied to the pump.
- ▶ Secure pipes to ceilings, walls, or floor using pipe clamps.

- ▶ Align pipes flush with pump connections using a bracket.

## 6.6 Electrical Connection

### ⚠ WARNING

#### Electrostatic Charge Buildup

Electric shock.

- ▶ Ground the pipes and the pump.

Electrical connection may only be performed by a qualified electrician.

#### Procedure

1. Heed the connection values on the motor's rating plate. The specified voltage must not be exceeded.
2. Only connect the motor to fuse-protected circuits to prevent excessive current consumption.
3. Connect the motor according to the circuit diagram in the terminal box of the motor.
4. Protect cable feedthroughs against penetration by moisture.
5. Turn on the motor for 2 to 3 seconds. Check the direction of rotation of the motor fan wheel.
6. Reverse the polarity if the direction of rotation is incorrect.

## 6.7 Connection of Sealing or Quenching Liquid (Optional)

For versions with double shaft seals, the shaft seal chamber must be flushed with sealing or quenching liquid.

- ▶ Use a suitable medium as a sealing or quenching liquid.

### 6.7.1 Installation of Pipes

1. Install and seal the supplied flushing tubes.
2. Install the inlet line on the **bottom** of the shaft seal.
3. Install the drain line on the **top** of the shaft seal.
4. Install the following fittings in the pipes:
  - Throttle valve in inlet line
  - Drain line with flowmeter (pressure gauge)

## 6.8 Cleaning

Only use cleaning agents that comply with the hygiene guidelines for the respective pumping medium.

1. Before sealing the pump ensure that there are no foreign objects inside the pump or pipes.
2. Seal the pump.
3. Connect the pipes.

4. Thoroughly clean the pump and the pipe system before initial use.

Check the required sealing pressure. For the maximum sealing pressure, see the specifications on the *Sectional Drawing* in the attached documents.

5. Turn on the motor.

## 7 Operation

### 7.1 Safety Instructions

#### Closed Valve in Discharge Line

Serious personal injury and material damage from bursting of system due to excessive pressure buildup.

- ▶ Before turning on and during operation of the system, ensure that all valves in the discharge line are open.
- ▶ Install bypass for pressure limitation.

#### Closed Valve in Suction Line

Damage to shaft seal by dry running of pump.

- ▶ Before turning on and during operation of the system, ensure that all valves in the suction line are open.
- ▶ Regulate the pump output only by means of the discharge-side valve.

#### No Medium in Pump

Dry running of pump. Damage to shaft seal.

- ▶ Ensure that there is always medium in the pump before and during operation.

### 7.2 Commencement of Operation

#### NOTICE

#### For double shaft seal: Stoppage of Sealing Liquid

Damage to shaft seal.

- ▶ Ensure that during operation:
  - The sealing liquid flows with the necessary pressure through the double shaft seal (see specifications on attached "*Sectional Drawing*").
  - The temperature of the sealing liquid T is maintained at < 70°C.

1. Open the valve in the suction line.
2. Open the valve in the discharge line.
3. Fill the pump and the suction line up to the upper edge of the pump with pumping medium. Allow any air pockets that are present to escape.
4. Only for pumps with sealing or quenching liquid:

### 7.3 Monitoring of Operation

#### 7.3.1 Safety Instructions

#### Foreign Objects in Pumping Medium

Blocking of rotors and shearing off of shafts.

- ▶ Rule out the possibility of foreign objects in the pumping medium.
- ▶ Install a current limiter to protect the gear motor.

#### Sudden Closing of Valves in Discharge Line

Damage to pumping medium by water hammers in the pump.

- ▶ During operation do not close the valve in the discharge line abruptly or for a long period of time.

#### Rapid Cooling of Pump

Tension cracks in pump.

- ▶ Do not rapidly cool the pump.

#### Cavitation and Dry Running of Pump

Damage to shaft seal.

- ▶ Ensure that suction-side valves are open during operation.

### 7.4 Stopping of Operation

1. Turn off the motor.
2. Close the valve in the suction line to prevent dry running of the pump.
3. Close the valve in the discharge line.

### 7.5 Pump Decommissioning

1. Turn off the motor.
2. Close the valve in the suction line.
3. Close the valve in the discharge line.
4. De-energize the pump.
5. Empty the pump.
6. Clean the pump as described in *Chapter 6.8, "Cleaning," page 12*.
7. Dry the pump.
8. Protect the interior of the pump from moisture.
9. Seal the pipe connections with caps to prevent penetration of dirt and foreign objects.
10. For additional steps, please see *Chapter 5, "Storage," page 10*.

## 8 Cleaning in Place

### 8.1 CIP Process

The FK-and FL-Positive Displacement Pumps are suitable for the CIP (Cleaning In Place) process. The following guidelines apply to the CIP process:

#### Example of a Cleaning Cycle

1. Perform preliminary flush with water.
2. Perform caustic flush with lye (NaOH; see *Table 2 CIP cleaning*).
3. Perform intermediate flush with water.
4. Perform acid flush with nitric acid (HNO<sub>3</sub>; see *Table 2 CIP cleaning*).
5. Flush with water.

The pump's differential pressure should be 2–3 bar so that adequate flow rates are reached in the pump.

Medium	Process Temperature [°C]
NaOH (approx. 1% to 2%)	80 to 85
HNO <sub>3</sub> (approx. 1%)	60 to 65

Table 2 CIP cleaning

If values deviate from these specifications, please contact *Fristam*.

### 8.2 SIP Process

#### NOTICE

#### Dry Running of Pump With Vapor

Damage to shaft seal.

- ▶ If vapor is flowing through the pipes, ensure that the pump is off.

The FK-and FL-Positive Displacement Pumps can only be used with the SIP (Sterilization In Place) process with the prior approval of *Fristam*.

Suitability depends on the selected elastomers.

The process temperature may not exceed 145°C.

## 9 Faults

For information on faults, possible causes, and remedies, please see *Chapter 11.4, "Troubleshooting Table," page 27*.

## 9.1 Safety Instructions

### Hot Surfaces

Contact burns from touching the pump. Pumping of hot media can cause the pump to become very hot.

- ▶ Let the pump cool down completely before working on it.
- ▶ Only touch the pump if you are wearing heat-resistant gloves.

## 10 Maintenance

For information on maintenance intervals, please see *Chapter 11.2, "Maintenance Intervals," page 27*.

### 10.1 Safety Instructions

#### Rotating Parts

Personal injury and material damage.

- ▶ Always turn off the pump motor and prevent it from being able to be turned on accidentally before working on the pump.

#### Falling or Unsecured Parts

Severe crush injuries.

- ▶ Always wear gloves when performing maintenance-related work.

#### Uncontrolled Outflow of Liquids

Personal injury and material damage from acid burns, poisoning, and contamination.

Before performing maintenance or cleaning work on the pump:

- ▶ Close the suction and discharge valves in front of and behind the pump.
- ▶ For double shaft seal: Block off the sealing or quenching liquid line.
- ▶ Before opening the pump completely empty the pump casing.

#### Rapid Cooling of Pump

Tension cracks in pump.

- ▶ Do not rapidly cool the pump.

#### Use of Hard Driving Tools

Scratching of polished surfaces.

- ▶ For polished surfaces, use a copper socket wrench socket.

## 10.2 Replacement Parts

Use of replacement parts that are not approved by *Fristam* can lead to serious personal injury and material damage. If you have any questions regarding approved replacement parts, please contact *Fristam*.

*Fristam* registers all shipped pumps. For ordering replacement parts, you require the following information:

1. Serial number of pump: See rating plate or number stamped into pump.
2. For replacement parts and materials designations, please see *Order-Related Documents* in the attached documents.

## 10.3 Inspection of Sealing and Quenching Liquid (Optional)

For pumps equipped for "sealing liquid" or "quenching liquid," the sealing liquid head must be checked. For information on maintenance intervals, please see *Table 13 on page 27*.

- ▶ Check the sealing liquid head and compare with the specified value.

The specified value can be found on the "Sectional Drawing of the Shaft Seal" in the *Order-Related Documents*. The *Order-Related Documents* are attached to this operator's manual.

The sealing liquid is heated by hot pumping medium and by operation of the pump.

- ▶ Ensure that the temperature T of the sealing liquid is < 70°C during operation.

## 10.4 Oil Level Check

The oil is checked on the oil sight glass (23), which can be found on the side of the gearbox.

For information on maintenance intervals, please see *Table 13 on page 27*.

## 10.5 Oil Change

For the FK-and FL-Positive Displacement Pumps, the oil must be changed at regular intervals. For information on maintenance intervals, please see *Table 13 on page 27*.

### Maintenance Intervals

Under severe operating conditions such as high humidity, aggressive environment, or large temperature fluctuations, the oil should be changed every 2,000 operating hours. Under normal conditions, an oil change should be performed once a year or every 4,000 operating hours.

### Lubricants and Amounts

For the lubricants, please see *Chapter 11.3, "Lubricant (Grease) Table," page 27*.

For the required amount of oil, please see *Table 3 Oil change: model FL and Table 4, "Oil change: model FK," page 16*.




Fig. 17 Oil level and oil change illustrated using the FL 100

21	Bleed screw
22	Screw plug
23	Oil sight glass

### Procedure

1. Turn on the motor and let it run until the normal operating temperature is reached.
2. Turn off the motor and prevent it from being able to be turned on accidentally.
3. Place a suitable oil collection container under the screw plug (22).
4. **Caution!** Hot oil. Skin burns from contact with hot oil.
  - ▶ Wear heat- and oil-resistant gloves.
- Loosen the bleed screw (21).
5. Loosen and remove the screw plug (22).
6. Drain the oil completely and dispose of oil in accordance with local regulations.
7. Clean the screw plug, the bleed screw, and the seals.
8. Install the screw plug and the bleed screw with the corresponding seals.
9. Fill with new oil, monitoring the oil level on the oil sight glass (23) in the process.

Model FL	Expected Oil Volume [l]		Oil
	Horizontal Orientation of Pipe Connections	Vertical Orientation of Pipe Connections	
FL/FL2 55	0.25	0.20	SAE 15W40
FL/FL2 75	0.60	0.50	
FL/FL2 100	1.80	1.30	
FL 130	2.00	1.80	
FL2 50	0.15	0.15	
FL2 58	0.25	0.25	

Table 3 Oil change: model FL

Model FK	Oil Volume		Oil
	Horizontal Orientation of Pipe Connections	Vertical Orientation of Pipe Connections	
25 and 25/30	1.0	0.7	SAE 15W40
40 and 40/45	2.5	1.8	
48	4.5	4.0	

Table 4 Oil change: model FK

## 10.6 Oil and Grease Change for FL 130

For the FL 130 positive displacement pump, the gears are lubricated with oil and the roller bearings with grease.

The pump's roller bearings have been lubricated for life.

### Procedure

- Turn on the motor and let it run until the normal operating temperature is reached.
- Turn off the motor and prevent it from being able to be turned on accidentally.
- Remove the pump casing. See *Chapter 10.9, "Pump Head Removal," page 16*.
- Remove the coupling guard.
- Remove the coupling tire.
- Place a suitable oil collection container under the screw plug **(22)**.
- Caution!** Hot oil. Skin burns from contact with hot oil.
  - ▶ Wear heat- and oil-resistant gloves.
 Loosen the bleed screw **(21)**.
- Loosen and remove the screw plug **(22)**.
- Drain the oil completely and dispose of oil in accordance with local regulations.
- Clean the screw plug, the bleed screw, and the seals.
- Install the screw plug and the bleed screw with the corresponding seals.
- Take the key off of the drive shaft.
- Take off the gear cover.
- Remove the shaft nuts and the retaining washers from the shafts.
- Take gears with O-rings off of the shafts.
- Remove keys.
- Force out the shaft in the direction of the pump casing.
- Remove the rotary shaft seal.
- Clean all parts. Check for damage and accuracy of fit.
- Relubricate tapered roller bearing and fill lubricant reservoir in gearbox with grease.
- Remount all parts in the reverse order.

## 10.7 Lubrication of Motor Bearings

- ▶ Lubricate the motor bearings in accordance with the gear motor manufacturer's specifications. See *"Supplier Documentation"* in the attached documents.

## 10.8 Shaft Seal Replacement

Replace the shaft seal if:

- Pumping medium or sealing or quenching liquid flows out of the pump on the atmosphere side.
- Sealing or quenching liquid leaks into the pumping medium.

### Procedure

- Remove the pump casing; see *Chapter 10.9, "Pump Head Removal," page 16*.
- Mount the pump casing; see *Chapter 10.10, "Pump Head Attachment," page 17*.
  - Mount the shaft seals on the shafts according to the respective application cases A to F.
  - Mount the rotors.
  - Attach the pump cover.

The exact procedure is described in the following sections.

## 10.9 Pump Head Removal

### Preparation

- Turn off the motor and prevent it from being able to be turned on accidentally.
- Close the valve in the discharge line.
- Close the valve in the suction line.
- For double shaft seal: Block off the sealing or quenching liquid line.
- Completely empty the pump.
- Loosen the suction and discharge connections.
- Take the pump out of the system.

### Procedure




Fig. 18 Detachment of pump cover illustrated using the FL 100

1. Loosen the nuts (24) on the pump cover.
2. Remove the nuts, the pump cover (25), and the cover seal (26).

Note: If the pump cover is hard to detach:

- ▶ FK positive displacement pumps  
There are two forcing screws with star knobs on the pump cover. Rotate the forcing screws clockwise until the cover detaches.
- ▶ FL positive displacement pumps  
Gently tap on the cover with a plastic hammer to detach the cover.




Fig. 19 Removal of rotors illustrated using the FL 100

3. **Warning:** Rotating machine parts. Severe pinching of hands.
  - ▶ Block the rotors (28) with wooden or plastic wedges.
 Loosen and remove the rotor fasteners (27) (rotor nuts or rotor screws) and the corresponding seals (29).
4. Take the rotors off of the drive and synchronizing shafts.
5. Loosen the threaded fasteners that connect the pump casing to the gearbox:
  - Model FL: Cap nuts on gearbox
  - Model FK: Socket screws inside pump casing




Fig. 20 Removal of shaft seal illustrated using the FL 100

6. Remove the pump casing (30).

7. **Note:** Loss of stationary bushing (32). Material damage.

- ▶ Determine the position of the stationary bushing. The stationary bushings are shown on the *Sectional Drawing* in the *Order-Related Documents*. The stationary bushings are marked by prick punch marks (indentations).
- ▶ Take the shaft seals (31) off of the pump casing (30) and the shafts. Remove the stationary bushings (32).
- ▶ Store the stationary bushings separately.

8. Continue as follows for the respective shaft seal:

#### For single shaft seal:

- ▶ Disassembly of the pump is now finished.

#### For double shaft seal:

1. The seal covers are located on the shafts and are connected to the gearbox. Please also see the *Sectional Drawing* in the *Order-Related Documents*.
2. Loosen the seal covers.
3. Remove the seal covers with the sealing elements.

## 10.10 Pump Head Attachment

The pump assembly is dependent on the respective pump size and model as well as the respective shaft seal. To determine which shaft seal you have, please see the *Order-Related Documents*.

### NOTICE

#### Incorrect Elastomers

Pump leakiness.

- ▶ Ensure that the elastomers are appropriate for the condition of the pumping medium. Please refer to the *Order-Related Documents*.

#### Preparation

- ▶ Clean all pump parts. Check for damage and accuracy of fit.
- ▶ If necessary, rework or replace pump parts.
- ▶ Assemble carefully in clean conditions. The seals can easily be damaged.
- ▶ Replace all O-rings.
- ▶ To reduce friction, wet the O-rings and the sliding faces with water, alcohol, or silicone grease.
- ▶ Clean the sealing surfaces of the mechanical seals with a degreaser, e.g., OKS 2610 Universal Cleaner. Do not allow the sealing surfaces to come into contact with oil or grease and do not touch with your fingers afterwards.

*Tip: The joint retaining compound "Euro Lock A64.80," e.g., is suitable for gluing in bearings and bushings.*

*Tip: The screw retaining compound "Euro Lock A24.10," e.g., is suitable for gluing in set screws.*

### 10.10.1 Important Markings

The rotors and stationary bushings must not be mixed up. They have been adapted to the synchronizing shaft or the drive shaft and are marked by prick punch marks (indentations).

- ▶ Before installing the stationary bushings and the rotors check the markings:
  - One indentation for drive shaft
  - Two indentations for synchronizing shaft

### 10.10.2 Mounting of Seals

The shaft seal built into the respective pump is given in the *Order-Related Documents* in the form of a *Sectional Drawing* and a *Replacement Parts List*.

The assembly of standard shaft seals is described in the following sections with the application cases A to F. The version for your order can deviate slightly from this.

If anything is unclear or if you require further information, please contact *Fristam*.

Application Case	Shaft Seal	Model	Pump Sizes
A	Single	FK and FL	All pump sizes
B	Single	FK 48	48
C	Single	FL 2	All pump sizes
D	Double	FK and FL	All pump sizes
E	Double	FL 2	50–100
F	Double	FL 2	130

Table 5 Standard shaft seals

Note: The following assembly procedures are only shown and described for the drive shaft. All instructions also apply to the synchronizing shaft.

#### Application Case A

To preassemble on the shaft:




Fig. 21 Preassembly on the shaft, application case A

1. Place O-rings (412.64) and (412.63) on the shaft.
2. Only for model FL 130:  
Insert cylindrical pins into the stationary bushing. Center the cylindrical pins; see the *Sectional Drawing* in the attached documents.
3. **Note:** Mixing up of the two stationary bushings. Material damage during pump operation from rotor blockage or scraping. The stationary bushings are designed for either the

drive shaft or the synchronizing shaft. See *Chapter 10.10.1, "Important Markings," page 18.*

- ▶ Slide the marked stationary bushing (54-3.60) onto the appropriate shaft.
4. Slide the rotating seal ring (472.60) onto the shaft.
  5. Only for model FL 130:  
Fasten the rotating seal ring and the stationary bushing with cylindrical pins to the shaft. The cylindrical pins are numbered 562.61 on the *Sectional Drawing*.

To preassemble the pump casing:




Fig. 22 Preassembly in the pump casing and final assembly on the shaft, application case A

6. Slide the spring (477.60) onto the mechanical seal chamber (47-2.60) and secure with set screw (904.60).  
**Note:** Incomplete, unstable installation. Material damage during pump operation.  
▶ Ensure that the set screw engages in the pump casing (101) to prevent twisting.
7. Place O-rings (412.65) and (412.60) into the mechanical seal chamber.
8. Insert the stationary seal ring (475.60) into the mechanical seal chamber.  
**Note:** Rotate the eccentric stationary seal ring slightly until it is lined up correctly for insertion.
9. Insert the mechanical seal chamber into the pump casing (101).
10. Mount the pump casing on the shafts and slide onto the gearbox.
11. **Note:** The pump casing does not lie flat on the gearbox. Material damage from warpage of pump casing.

- Screw the pump casing to the gearbox using the following fasteners according to the given model:

Model FL: Cap nuts on gearbox

Model FK: Socket screws inside pump casing

To complete assembly on the shaft:

12. Only for model FL 100/130:

Insert cylindrical pins into the sleeve (**520.60**). Insert the pins completely into the sleeve. See *Sectional Drawing*.

13. Insert the O-ring (**412.62**) into the sleeve.

14. Place the sleeve on the shaft.

Only for model FL 100/130: Ensure that the cylindrical pins engage in the slots on the shaft.

15. Finish the assembly of the shaft seal by attaching the rotors; see *Chapter 10.10.3, "Mounting of the Rotors," page 21*.

### Application Case B

To preassemble the pump casing:




Fig. 23 Preassembly of the pump casing, application case B

1. Equip the mechanical seal chamber (**47-2.60**) with an O-ring (**412.60**) and guide it into the pump casing (**101**).
2. Place a washer (**550.63**) on the mechanical seal chamber and secure to pump casing with snap ring (**93-1.60**).
3. Mount the preassembled pump casing on the shafts and slide onto the gearbox.
4. **Note:** The pump casing does not lie flat on the gearbox. Material damage from warpage of pump casing.
  - Screw the pump casing to the gearbox using hex cap screws.

To complete assembly on the shaft:




Fig. 24 Application case B, final assembly on the shaft

5. Equip the stationary seal ring (**475.50**) with an O-ring (**412.52**).
6. Slide the stationary seal ring onto the shaft so that the slots on the stationary seal ring engage with the cylindrical pins on the pump casing.
7. **Note:** Mixing up of the two stationary bushings. Material damage during pump operation from rotor blockage or scraping. The stationary bushings are designed for either the drive shaft or the synchronizing shaft. See *Chapter 10.10.1, "Important Markings," page 18*.
  - Slide the marked stationary bushing (**54-3.60**) onto the appropriate shaft.
8. Equip the seal driver (**485.60**) with an O-ring (**412.62**).
9. Equip the rotating seal ring (**472.50**) with the spring (**477.50**) and the O-ring (**412.51**).
10. Fit the rotating seal ring and the seal driver together.
 

Note: Ensure that the cylindrical pins (**560.50**) engage in the slots on the seal driver.
11. Slide the rotating seal ring and the seal driver onto the shaft.
12. Finish the assembly of the shaft seal by attaching the rotors; see *Chapter 10.10.3, "Mounting of the Rotors," page 21*.

### Application Case C

To preassemble the pump casing:




Fig. 25 Application case C

1. Equip the pump casing (101) with an O-ring (412.65).
2. Equip the stationary seal ring (475.60) with the spring (477.60) and insert into the pump casing.  
 Note: Rotate the eccentric stationary seal ring slightly until it is lined up correctly for insertion.
3. Slide the rotating seal ring (472.60) onto the shaft.
4. Mount the pump casing (101) onto the shafts and slide onto the gearbox.
5. **Note:** The pump casing does not lie flat on the gearbox. Material damage from warpage of pump casing.
  - Place cap nuts on the studs (902.3) and screw the pump casing to the gearbox.

To complete assembly on the shaft (II):

6. Equip the stationary bushing (54-3.60) with an O-ring (412.82).
7. **Note:** Mixing up of the two stationary bushings. Material damage during pump operation from rotor blockage or scraping. The stationary bushings are designed for either the drive shaft or the synchronizing shaft. See Chapter 10.10.1, "Important Markings," page 18.
  - Slide the stationary bushing onto the appropriate shaft.
8. Place the O-ring (412.64) into the groove on the rotor.
9. Finish the assembly of the shaft seal by attaching the rotors; see Chapter 10.10.3, "Mounting of the Rotors," page 21.

### Application Case D




Fig. 26 Standard shaft seal, application case D

1. Screw the flushing tubes (710.60) into the seal cover (471.60) and seal.
2. Insert the rotary shaft seal (421.60) into the seal cover.  
 Note: Heed the installation direction for the rotary shaft seal. See Sectional Drawing.
3. Use socket screws (914.60) to screw the seal cover to the gearbox (87-1).
4. Place an O-ring (412.67) on the outside of the seal cover.
5. Continue as described in Chapter, "Application Case A," page 18.

### Application Case E




Fig. 27 Standard shaft seal, application case E

1. Screw the flushing tubes (710.60) into the seal cover (47-2.60) and seal.

2. Use socket screws (**914.60**) to screw the seal cover to the gearbox (**87-1**).
3. Insert the stationary seal ring (**475.61**), the spring (**477.61**), and the O-ring (**412.67**) into the seal cover.
4. Insert the O-ring (**412.60**) into the seal cover.
5. Continue as described in Chapter, "Application Case C," page 20.

### Application Case F




Fig. 28 Standard application case F

1. Screw the flushing tubes (**710.60**) into the seal cover (**47-2.60**) and seal.
2. Mount the seal cover on the studs on the gearbox (**87-1**).
3. Insert the stationary seal ring (**475.61**), the spring (**477.61**), and the O-ring (**412.67**) into the seal cover.
4. Insert the O-ring (**412.60**) into the seal cover.
5. Continue as described in Chapter, "Application Case C," page 20.

### 10.10.3 Mounting of the Rotors




Fig. 29 Installation of rotors illustrated using the FL 100

1. **Note:** Mixing up of the two rotors. Material damage during pump operation from rotor blockage or scraping. The rotors are designed for either the drive shaft or the synchronizing shaft. See Chapter 10.10.1, "Important Markings," page 18.

- Mount the rotors (**34**) with O-rings (**35**) on the appropriate shafts.

2. Depending on the given fastener type, attach the rotor nut or the rotor screw (**33**) as follows:

#### Rotor Nuts

1. Open the polyamide snap ring and place in the shaft groove.
2. Screw the rotor nut (**33**) hand-tight onto the shaft.

#### Rotor Screws

1. Place O-rings on the rotor screw.  
Only for model FK 25-40/45: Place O-rings and eccentric washer on the rotor screw.
2. Screw the rotor screw hand-tight into the shaft.  
Only for model FK 25-40/45: Align the eccentric washer with the shaft.

3. **Warning:** Rotating machine parts. Severe pinching of hands.  
► Block the rotors with wooden or plastic wedges.
4. Tighten the rotor fasteners to the specified tightening torque. See Table 6, "Tightening torques for rotor fasteners," page 21.

Model	Pump Size	Thread	Rotor Fastener Tightening Torque [Nm]	
			Rotor Nut	Rotor Screw
FL	50	M8	–	11
	55	M16 × 1.5	50	–
	58	M16 × 1.5	50	–
	75	M24 × 1.5	100	–
	100	M30 × 2	200	–
FK	130	M40 × 2	300	–
	25 and 25/30	M10	–	30
	40 and 40/45	M12 × 1.25	–	35
	48	M30 × 2	200	–

Table 6 Tightening torques for rotor fasteners

### 10.10.4 Pump Sealing




Fig. 30 Fastening of pump cover illustrated using the FL 100

1. Equip the pump cover (37) with an O-ring (36).
2. Slide the pump cover onto the pump casing and screw on with nuts (38).

#### For Pumps With Cover Bushings

1. Rotate the shafts on the coupling by hand to check if they rotate freely or not.
2. Based on the result, take one of the following procedures:

##### The rotors scrape against the pump cover.

- ▶ The pump cover is not properly aligned. Contact *Fristam*. The pump cover must be realigned and repinned.

##### The shafts can be rotated.

- ▶ The pump is sealed correctly.

### 10.11 Shaft Bearing Replacement

- ▶ Contact *Fristam*.

### 10.12 Coupling Replacement

- ▶ Only use couplings that are appropriate for the gear capacity. If you have any questions, please contact *Fristam*.

#### Procedure

1. Turn off the motor and prevent it from being able to be turned on accidentally.
2. Remove the coupling guard.
3. Remove the coupling tire.
4. Detach the motor from the base frame and remove.
5. Dispose of the old coupling parts in an environmentally friendly manner.
6. Place new coupling parts (tire, flanges, possibly clamping rings) on the drive shaft and on the gear shaft.
7. Place the motor on the base frame or the foundation and slightly tighten the fastening screws.

8. Check the parallel and angular misalignment of the shafts.




Fig. 31 Parallel misalignment




Fig. 32 Angular misalignment

9. Minimize deviations from the angular and parallel misalignment. Realign the shafts if necessary.
10. Screw the motor to the base frame or the foundation.
11. For information on the spacing between the two coupling flanges, please see the coupling installation manual. See *Supplier Documentation* in the attached documents.
12. Fasten the coupling flanges with the given spacing onto the shaft.
13. Fasten the coupling tire. Tighten the screws uniformly and crosswise. Heed the given tightening torques in the coupling installation manual.
14. Mount the coupling guard.

### 10.13 Gear Motor Replacement

Model FKF: To replace the gear motor, please contact *Fristam*.

#### Coupling

The coupling installation manual can be found in the supplier documentation in the attached documents.

#### NOTICE

#### Gear Motor Oversized

Use of an incorrectly sized gear motor can result in serious damage to the pump unit.

- ▶ Only replace the gear motor with one with the same rating; see *Motor Supplier Documentation*.

#### Procedure

1. Turn off the gear motor and prevent it from being able to be turned on accidentally.
2. Remove the coupling guard.
3. Remove the coupling tire.
4. Take the coupling parts off of the gear motor.
5. Detach the old gear motor from the base frame or the foundation.
6. Dispose of the old gear motor. See *Chapter 2.6, "Disposal," page 7*.

7. Remove protective coatings and grease from all coupling parts.
8. Place coupling parts (tire, flanges, possibly clamping rings) on the drive shaft and on the replacement motor shaft.
9. Place the replacement motor on the base frame or the foundation and fasten.
10. Continue with step 8, "Check the parallel and angular misalignment of the shafts," in Chapter 10.12, "Coupling Replacement," page 22.

## 10.14 Checking of the Clearances

The clearance ensures that the rotors can rotate freely. The clearance must be checked if the following parts are replaced:

- Shaft bearing and shaft
- Rotor

### Measurement Types

The clearance between the rotor and the pump casing is measured. The following measurements must be made:

- Axial clearance measurement

The measurement is dependent on the positions of the rotors on the shafts.

- Model FK: Radial clearance measurement

The measurement is dependent on the position of the pump casing on the gearbox.

### 10.14.1 Preparation of Pump for Measurement

#### Prerequisites

- Pump cover has been removed.
- Rotors have been removed.

#### Procedure




Fig. 33 Installation of rotors illustrated using the FL 100

1. **Note:** Mixing up of the two rotors. Material damage during pump operation from rotor blockage or scraping. The rotors are designed for either the drive shaft or the synchronizing shaft. See Chapter 10.10.1, "Important Markings," page 18.
  - Mount the rotors (40) with O-rings (41) on the appropriate shafts.

2. Depending on the given fastener type, attach the rotor nut or the rotor screw as follows:

#### Rotor Nuts

Note: The polyamide snap ring is not attached for the clearance measurement.

- Screw the rotor nut (39) hand-tight onto the shaft.

#### Rotor Screws

- Place O-rings and washer on the rotor screw.

Only for model FK 25-40/45: Place O-rings and eccentric washer on the rotor screw.

- Screw the rotor screw hand-tight into the shaft.

Only for model FK 25-40/45: Align the eccentric washer with the shaft.

3. **Warning:** Rotating machine parts. Severe pinching of hands.
  - Block the rotors (40) with wooden or plastic wedges.
4. Tighten the rotor fasteners to the specified tightening torque. See Table 7, "Tightening torques for rotor fasteners during clearance measurement," page 23.

Model	Pump Size	Thread	Tightening Torque [Nm]
FL	50	M8	11
	55	M16 × 1.5	25
	58	M16 × 1.5	25
	75	M24 × 1.5	50
	100	M30 × 2	100
	130	M40 × 2	100
FK	25 and 25/30	M10	30
	40 and 40/45	M12 × 1.25	35
	48	M30 × 2	100

Table 7 Tightening torques for rotor fasteners during clearance measurement

### 10.14.2 Measurement of Axial Clearance




Fig. 34 Measurement of axial clearance

#### Prerequisites

Pump has been prepared for the measurement.

#### Procedure

1. Measure the clearance **A** between the pump casing (**42**) and the rotor (**43**) using vernier calipers.
2. **Note:** Clearance too small. Destruction of pump.
  - ▶ Check your order documents to determine if standard or high-temperature rotors are installed in the pump. If necessary, contact *Fristam*.
3. Compare the clearance with the value in *Table 8 Clearances*.

Note: When rotors are used they undergo wear. This increases tolerance ranges slightly.

Model	Pump Size	Axial Clearance in mm	
		Standard Rotors	High-Temperature Rotors
FL	50	0.04–0.06	0.06–0.08
	55 S/L	0.14–0.16	0.19–0.21
	58 S/L	0.10–0.13	0.15–0.18
	75 S/L	0.19–0.21	0.24–0.26
	100 S/L	0.24–0.26	0.29–0.31
	130S	0.24–0.26	0.30–0.32
	130L	0.27–0.29	0.33–0.35
FK	25 and 25/30	0.03	0.11–0.13
	40 and 40/45	0.05–0.08	0.11–0.13
	48	0.15–0.17	0.25–0.27

Table 8 Clearances

4. If the clearance is not within the specified tolerance range:

#### Clearance too large

- ▶ See Chapter, "Grinding of Stationary Bushing," page 24.

#### Clearance too small

- ▶ See Chapter, "Addition of Shims," page 24.

5. If the clearance is within the specified tolerance range, go to Chapter 10.14.3, "Model FK: Measurement of Radial Clearance," page 25.

#### Grinding of Stationary Bushing

1. Remove the pump casing; see Chapter 10.9, "Pump Head Removal," page 16.
2. Take the stationary bushing out of the shaft seal set. The positions of the stationary bushings are shown on the *Sectional Drawing* in the *Order-Related Documents* in the attached documents. The stationary bushings are marked by prick punch marks (indentations); see Chapter 10.10.1, "Important Markings," page 18.
3. Grind the stationary bushing down to the required dimension.
4. Mount the pump casing.

See Chapter 10.10, "Pump Head Attachment," page 17.

5. Measure the clearance again.

#### Addition of Shims

1. **Warning:** Rotating machine parts. Severe pinching of hands.
  - ▶ Block the rotors with wooden or plastic wedges.
2. Remove the rotor nuts and rotors.
3. Temporarily place the required shims on the shafts in these positions.
4. Install the rotors and the rotor nuts as described in Chapter 10.14.1, "Preparation of Pump for Measurement," page 23.
5. Measure the clearance again.




Fig. 35 Addition of shims

6. Clearance correct: Remove the pump casing to place the shims in the correct positions.

See Chapter 10.9, "Pump Head Removal," page 16.

7. Place the shims (45) and the stationary bushing (44) on the shaft.
8. Continue as in Chapter 10.10, "Pump Head Attachment," page 17 to Chapter 10.10.3, "Mounting of the Rotors," page 21.
9. Continue as follows for the respective model:

**Model FL**

- ▶ Seal the pump; see Chapter 10.10.4, "Pump Sealing," page 22. The clearance measurement is finished.

**Model FK**

- ▶ Continue with 10.14.3 Model FK: Measurement of Radial Clearance.

**10.14.3 Model FK: Measurement of Radial Clearance**

**Prerequisites**

Pump has been prepared for the measurement.

**Procedure**

1. Measure the clearance between the rotor and the casing at the following positions using a leaf feeler gauge:




Fig. 36 Model FK: measurement of radial clearance

2. Check if the drive shaft can be rotated by hand at the rotor fastener or not.
3. Based on the result, take one of the following procedures:

**The drive shaft cannot be rotated.**

If the drive shaft cannot be rotated, the clearances are too small.

- ▶ Contact *Fristam* to order the documents for repinning of the pump casing.

**The drive shaft can be rotated.**

If the drive shaft can be rotated and the clearances are the same at all measuring points, seal the pump as follows:

1. First remove the rotor nuts again.
2. Proceed as described in the following chapters:  
*Chapter 10.10.3, "Mounting of the Rotors," page 21 and Chapter 10.10.4, "Pump Sealing," page 22.*
3. The clearance measurement is finished.

## 11 Appendix 1

### 11.1 Specifications

#### 11.1.1 Tightening Torques

Tightening Torques for Screws and Nuts

**Material: Steel, Strength Class: 8.8**

Thread	M8	M10	M12	M16
Tightening Torque [Nm]	25	49	85	210

**Material: Steel, Strength Class: 70**

Thread	M8	M10	M12	M16
Tightening Torque [Nm]	17.5	35	62	144

#### 11.1.2 Maximum Discharge Pressures

##### Model FL

Pump Size	Maximum Discharge Pressure [bar]
FL50	10
FL55S	9
FL55L	6
FL58S	9
FL58L	8
FL75S	12
FL75L	8
FL100S	12
FL100L	8
FL130S	12
FL 130L	8

Table 9 Maximum discharge pressures for model FL

##### Models FK and FKH

Pump Size/Version	Maximum Discharge Pressure [bar]
All pump sizes Without cover bushing	5
FKFH/FKFNH 25	15
FKFHV/FKFNHV 25	12
FKFH/FKFNH 25/30	12
FKFHV/FKFNHV 25/30	12
FKFHV/FKFNH 40	18
FKFHV/FKFNHV 40	12
FKFH/FKFNHV 40/45	12
FKFHV/FKFNHV 40/45	12
FKNH/FKNHV 48	20

Table 10 Maximum discharge pressures for models FK and FKH

#### 11.1.3 Maximum Medium Temperatures

##### Model FL

Rotor Type	Maximum Temperature [°C]
Standard rotors	90
High-temperature rotors	160

Table 11 Maximum medium temperatures for model FL

##### Model FK

Rotor Type	Maximum Temperature [°C]
Standard rotors	95
High-temperature rotors	150

Table 12 Maximum medium temperatures for model FK

## 11.2 Maintenance Intervals

Interval	Model	Maintenance Task	Chapter
Once a day	All	Check the oil level.	See Chapter 10.4, "Oil Level Check," page 15.
Once a day	"Sealing and Quenching Liquid" option	Check the sealing or quenching liquid.	See Chapter 10.3, "Inspection of Sealing and Quenching Liquid (Optional)," page 15.
2,000 h	All, under severe operating conditions	Change the oil.	See Chapter 10.5, "Oil Change," page 15.
4,000 h	All, under normal operating conditions	Change the oil.	See Chapter 10.5, "Oil Change," page 15.
When necessary	All	Replace the shaft seal.	See Chapter 10.8, "Shaft Seal Replacement," page 16.
When necessary	FL 130	Replace the roller bearings.	Chapter 10.6, "Oil and Grease Change for FL 130," page 16
When necessary	All	Replace the coupling.	See 10.12, "Coupling Replacement".
When necessary	All	Replace the motor.	See Chapter 10.13, "Gear Motor Replacement," page 22.
According to manufacturer's specifications	All	Lubricate the motor bearings; for more information on motor maintenance intervals, please see the <i>Motor Supplier Documentation</i> .	See Chapter 10.7, "Lubrication of Motor Bearings," page 16.

Table 13 Maintenance intervals

## 11.3 Lubricant (Grease) Table

Model	ARAL	BP	DEA/Texaco	ELF	ESSO	Mobil	Shell
FL	Aralub HTR2	Energrease HTG	Paragon EP 2	GRX 500	HT Grease 275	MobiltempSHC 100	Darina Grease 2

Table 14 Lubricant table

Other brand-name lubricants with equivalent qualities and viscosities may also be used.

## 11.4 Troubleshooting Table

Problem	Possible Cause	Remedy
<b>Pump either does not pump or pumps irregularly.</b>	Pump interior not completely filled with liquid; pump interior not vented; discharge valve closed.	Fill pump interior with liquid; open discharge valve.
	Suction line blocked or clogged.	Open or clean suction line.
	Pump with geodesic suction head <sup>1</sup> : liquid falls at standstill and casing runs dry.	Install foot valve in suction line.
	Suction line leaky; seal on pump cover leaky and drawing in air.	Seal suction line; replace cover seal.
	Air pocket in suction line.	Lay suction line as straight as possible and at steady incline.
	Pump blocked; foreign objects in pump.	Clean pump interior; perform visual inspection; contact <i>Fristam</i> .
	Foot valve blocked or contaminated.	Clean foot valve; reestablish proper function.
	Viscosity of pumping medium too high; medium does not flow well because too viscous.	Contact <i>Fristam</i> .
<b>Flow rate too high.</b>	Coupling punctured due to overloading.	Contact <i>Fristam</i> .
	Pump oversized.	Contact <i>Fristam</i> .
	No regulating valve behind discharge port.	Install regulating valve; add throttle control; reduce motor speed.

Table 15 Troubleshooting table

Problem	Possible Cause	Remedy
<b>Flow rate too low; discharge head too low.</b>	Selected pump too small; motor speed too low due to incorrect voltage.	Contact <i>Fristam</i> ; connect according to motor rating plate.
	Suction line leaky and drawing in air.	Seal leaks.
	Viscosity of pumping medium too high (too viscous).	Possibly convert to heating; contact <i>Fristam</i> .
	Rotor wear; clearance too large.	Repair.
	Back pressure too high; relief valve (if supplied) regulates incorrectly.	Set relief valve correctly.
	Direction of rotation incorrect.	Correct pipe and electrical connections.
<b>Metal noise.</b>	Foreign objects in pump interior.	Disassemble, inspect, and (if necessary) repair.
	Rotors mechanically catching; rotor nuts loose.	Disassemble, rework, and set correct clearance.
	Excessive wear of bearings and gearwheels from overloading or inadequate lubrication.	Disassemble, inspect, and repair. Regular maintenance; lubricant service.
	Speed too high.	Use motor with frequency converter; contact <i>Fristam</i> .
	Pump running dry; shaft seal running dry.	Immediately supply pumping medium; immediately supply sealing water.
	No high-temperature rotors (with larger clearance) installed for pumping medium at elevated temperatures.	Check operating conditions; Contact <i>Fristam</i> .
	Excessive throttling of discharge line.	Check operating conditions; contact <i>Fristam</i> .
<b>Flow noise.</b>	Operation in overload or part-load range.	Adjust working point to design.
	Flow losses in suction line too high.	Increase nominal sizes; rule out the possibility of throttling.
	Cavitation.	Check condition for NPSH rating; see <i>Chapter 6.5, "Installation of Pipes," page 12</i> . Contact <i>Fristam</i> .
<b>Vibrations.</b>	Weight and hydraulic forces of pipes stressing the pump.	Support pipes so that pump is not stressed; install vibration dampers if necessary; keep water hammers away from pump.
<b>Excessive heating of pump shaft bearings and drive gear.</b>	Bearing damage.	Disassemble; replace bearings.
	Lubricating oil inadequate.	Change lubricating oil (see <i>Table 3 on page 15</i> ); perform maintenance at regular intervals (see <i>Table 13 on page 27</i> ).
<b>Motor power consumption too high.</b>	Resistance in discharge line too high; pump throttled too much; flow rate too low.	Increase nominal size of discharge line; open throttle valve; reduce speed using frequency converter on motor or control gear.
	Viscosity and/or density of pumping medium too high.	Contact <i>Fristam</i> .
	Rotors installed with inadequate clearance contrary to specifications.	Contact <i>Fristam</i> .
	Massive damage to pump shaft bearings or gear motor.	Disassemble and inspect; contact <i>Fristam</i> .

Table 15 Troubleshooting table

Problem	Possible Cause	Remedy
<b>Leakage at shaft seal.</b>	Shaft seal mechanical damage or wear.	Replace mechanical seal and rotary shaft seal (including all secondary seals); possibly convert to different materials; contact <i>Fristam</i> .
	Shaft seal running dry; suction head too high; pumping medium temperature too high.	Decrease geodesic suction head; use double shaft seal; contact <i>Fristam</i> .
	Sealing or flushing water pressure too high.	Adjust using throttle valve and pressure gauge.
	Shaft seal materials not chemically resistant to pumping medium; medium temperature too high.	Contact <i>Fristam</i> ; convert to cooling or double shaft seal.
	Sealing or flushing water pressure too low; sealing water tubes clogged; shaft seal crusted or damaged.	Adjust sealing water inlet and outlet; clean sealing water tubes; replace shaft seal.
	Sealing water contaminated or too hot.	Use drinking water-quality water with temperature of max. 70°C.

Table 15 Troubleshooting table

<sup>1</sup>The "geodesic suction head" is the vertical distance between the suction-side liquid level and the center of the pump pipe connections.

## 11.5 Number Key

The number key is for the attached *Sectional Drawing*. When ordering replacement parts, please specify the *Part Number* and the *Name*.

Part Number	Name	Part Number	Name	Part Number	Name
101	Pump casing	479	Left spring	801	Flange motor
108	Stage casing	481	Bellows	87-1	Gearbox
160	Cover	482	Bellows support	87-2	Gear cover
13-1	Back casing panel	484	Spring retainer	87-3	Gear cap
13-2	Housing insert	485	Seal driver	87-4	Gear base
130	Casing part	500	Ring	839	Contact
132	Spacer	50-1	Split lock washer	872	Gearwheel
154	Intermediate wall	50-2	V-ring	89-1	Filler piece
156	Outlet side	50-3.60	Set collar	89-2	Spherical cap frame
18-1	Spherical cap bearing	504	Spacer ring	89-3	Motor foot
18-2	Vibration damper	520	Sleeve	89-4	Handle
182	Base	523	Shaft sleeve	89-5	Protective cap
21-1	Synchronizing shaft	524	Shaft protective sleeve	89-6	Wheel
213	Drive shaft	525	Spacer sleeve	89-8	Flat bar steel
23-1	Rotor	54-1	Cover bushing	89-9	Motor bracket
26-1	Bracket for mechanical seal chamber	54-2	Bushing	89-10	Motor bracket
230	Impeller	54-3	Stationary bushing	89-11	Spherical cap base support
32-1	Angular contact ball bearing	540	Bushing	892	Base plate
32-2	Cylindrical roller bearing	543	Spacer bushing	894	Console
32-3	Deep groove ball bearing	55-1	Serrated lock washer	897	Guide piece
32-4	Tapered roller bearing	550	Washer	90-1	Stud bolt
321	Radial ball bearing	551	Spacer washer	90-3	Tapered pin
322	Radial roller bearing	554	Washer	90-4	Half-length taper grooved pin
325	Needle bearing	561	Grooved pin	90-5	Eyebolt
330	Bearing support	56-1	Roll pin	900	Screw
331	Bearing block	56-2	Grooved pin with round head	901	Hex cap screw
341	Drive lantern	560	Pin	902	Threaded stud
344	Bearing support lantern	562	Cylindrical pin	903	Screw plug
350	Bearing housing	59-2	Dished-type lock washer	904	Set screw
360	Bearing cap	59-3	Shrink ring	909	Adjusting screw
40-4	Half-length taper grooved pin	59-4	Lantern	91-1	Slotted cheese head screw
400	Flat seal	59-5	Membrane	913	Bleed screw
410	Profile seal	642	Oil level sight glass	914	Socket screw
411	Gasket	680	Enclosure	92-1	Star knob nut, long
412	O-ring	68-1	Support plate	92-2	Star knob nut, short
421	Rotary shaft seal	68-2	Foam strip	92-3	Cap nut
422	Felt ring	68-3	Bracket for enclosure	92-4	Rotor nut
433	Mechanical seal	68-4	Orifice plate	92-5	Forcing screw
45-1	Thrust ring	68-5	CF guard plate	92-6	Rotor fastener
451	Stuffing box housing	681	Coupling guard	92-7	Nut with flange
454	Stuffing box ring	701	Bypass line	920	Hex nut
47-1	Spring with washer	710	Pipe	921	Shaft nut
47-2	Mechanical seal chamber	71-1	Connection pipe	922	Impeller nut
47-3	Wedge seal	715	Hose pipe	923	Bearing nut
47-5	Ring nut	722	Flange adapter	93-1	Snap ring
471	Seal cover	723	Flange	930	Retainer
472	Rotating seal ring	724	Blind flange	931	Retaining washer
474	Thrust collar	733	Pipe clamp	932	Snap ring
475	Stationary seal ring	751	Valve housing	940	Key
476	Stationary seal ring support	755	Valve bolt	941	Woodruff key
477	Mechanical seal spring	756	Valve spring	950	Spring
478	Right spring	759	Valve plate		
		800	Motor		

## 11.6 Declaration of Conformity

Note: The following declaration does not apply to the option "Pump Without Motor."

*Fristam* hereby declares that the pump unit complies with all applicable requirements of the Machinery Directive (2006/42/EC).

The machine also complies with all requirements of the Low Voltage Directive (2006/95/EC) and the EMC Directive (2004/108/EC).

The following harmonized standards have been applied:

- DIN EN 12100-1  
Safety of machinery - Basic concepts, general principles for design, Part 1: Basic terminology, methodology
- DIN EN 12100-2  
Safety of machinery - Basic concepts, general principles for design, Part 2: Technical principles

Authorized documentation representative:

Function: Quality Officer

Address: FRISTAM Pumpen KG (GmbH & Co.)  
Kurt-A.-Körber-Chaussee 55  
21033 Hamburg  
GERMANY



## 12 Appendix 2 – Assembly Instructions (Optional)

### 12.1 Safety Instructions

These assembly instructions are addressed solely to specialized employees.

### 12.2 Scope

These assembly instructions apply to pumps supplied without motors (optional) and preassembled.




Fig. 37 Incomplete machine: pump without motor, coupling, or base frame illustrated using the FL 100

The following specifications in the "Original Operator's Manual" for complete machines do not apply in this case:

- Chapter 11.6, "Declaration of Conformity," page 31,
- Chapter 11.1.2, "Maximum Discharge Pressures," page 26.

### 12.3 Rating Plate




Fig. 38 Rating plate for pump without drive

46	Manufacturer
47	Type: pump series, pump size, model, version
48	SN: serial number of the pump
49	H: discharge head [m]; without drive: no indication
50	P: motor output [kW]; without drive: no indication
51	Year of manufacture
52	m: mass (pump without drive) [kg]
53	$n_R$ : rated speed [1/min]; without drive: no indication
54	Q: flow rate [ $m^3/h$ ]; without drive: no indication

### 12.4 Moving Without Motor

Transportation may only be performed by trained personnel.

The pump can be moved using an industrial truck or a crane.

Always move the pump in the installation condition.

#### 12.4.1 Safety Instructions

##### Falling or Unsecured Parts

Severe crush injuries.

- ▶ Always wear gloves when performing transportation-related work.

##### Incorrect Positioning of Pump for Transportation

Leakage of caustic, toxic, or contaminating liquids. Personal injury and material damage from contamination.

- ▶ Always move the pump in the installation condition.

##### Open, Unsealed Pipe Fittings

Material damage from contamination, impact, or moisture in the pump.

- ▶ Remove the pipe fitting covers just prior to connection to the pipes.

#### 12.4.2 Moving With Industrial Trucks

##### ⚠ WARNING

##### Unsecured Parts

Serious injuries, pinching of extremities, material damage.

- ▶ Before moving the pump secure it to prevent it from tipping over. Secure the pump to the pallet with tie-down straps, or screw the pump to the pallet.

##### Preparation

- ▶ Ensure that the pump is adequately secured to the pallet, for example, with straps; see Fig. 39, "Moving with pallet truck," page 34.

### Procedure

1. Pick up the pallet with the forks on the industrial truck.
2. Carefully move the pallet to the designated location and set down.




Fig. 39 Moving with pallet truck

### 12.4.3 Moving With Crane

#### ⚠ WARNING

#### Falling Parts

Death from crushing, pinching of extremities, material damage.

- ▶ Only use suitable means of conveyance and hoists that are designed for the total weight of the pump.

Information on the pump weight can be found on the pump's rating plate as well as in the *Order-Related Documents* in the attached documents.

- ▶ Do not leave the pump in a raised position for longer than necessary.
- ▶ Ensure that the area below the pump is clear of people.

#### ⚠ WARNING

#### Swinging Parts

Crushing and serious injuries.

- ▶ Start and stop the crane with pump smoothly.
- ▶ Ensure that the danger zone of the pump is clear of people.

#### Auxiliary Equipment

- Hoists: round slings tested in accordance with DIN EN 1492-1 and 1492-2
- Eyebolt and suitable eyebolt lifting devices

#### Preparation

- ▶ Remove load-securing devices.




Fig. 40 Moving with crane and eyebolt illustrated using the FL100

To move the pump with the eyebolt:

1. Screw the eyebolt completely into the threaded hole (55) intended for it.
2. Fasten the crane hook to the eyebolt; use a shackle if necessary.
3. Lift the pump.




Fig. 41 Moving with crane and round sling illustrated using the FL100

To move the pump with the round sling:

1. Wrap the round sling around the casing and the gear cover.  
See Fig. 41, "Moving with crane and round sling illustrated using the FL100," page 34.

2. For double shaft seal:

**Note:** Round sling compresses sealing water tubes. Material damage to double shaft seal.

- ▶ Do not lay the round sling on the sealing water tubes.
3. Cross one sling loop over the other and hook over the hook to ensure that the belt will not slip on the hook.
  4. Position the center of gravity to ensure that the pump is lifted horizontally.
  5. Lift the pump.

### 12.5 Installation Location

Please see the operator's manual *Chapter 6.2, "Installation Location," page 11* for the basic installation location requirements.

## 12.6 Pump Installation

### Prerequisites (Customer-Side)

- Suitable gear motor
- Adequately sized coupling
- Common installation surface for gear motor and pump so that pump shaft can be aligned with gear motor shaft

NOTICE
--------

### Incorrectly Designed Motor and Coupling

Destruction of pump and coupling.

- ▶ Only use motors and couplings that have been adapted to the pump characteristic curves. If you have any questions, please contact *Fristam*.

Note: Please see the coupling supplier documentation for reference dimensions for the coupling.

### Procedure

1. Mount the coupling parts on the drive shaft and the gear shaft.
2. Place the pump on the base frame or the foundation so that the drive shaft can be connected to the gear shaft with the coupling.
3. Screw the threaded fastener slightly into the pump base.
4. Check the parallel and angular misalignment of the drive and gear shafts.
5. Minimize deviations from the angular and shaft misalignment. If necessary, realign or add shims.
6. Screw the pump and gear to the base frame or the foundation.
7. Fasten the coupling according to the coupling manufacturer's specifications.
8. Install a noncontact, barrier-providing protective device (coupling guard) in accordance with Section 1.4, entitled "Required Characteristics of Guards and Protective Devices," of the Machinery Directive 2006/42/EC.
9. The pump is now installed. Do not commission the pump unless the requirements of the EC Machinery Directive are met for the complete machine.

Note: Continue with *Chapter 4, "Transportation," page 9*.









---

Fristam Pumpen KG (GmbH & Co.)  
Kurt-A.-Körber-Chaussee 55  
21033 Hamburg  
GERMANY

Tel.: +49-40-72556-0

Fax: +49-40-72556-166

E-mail: [info@fristam.de](mailto:info@fristam.de)